



Wall Mounting Options



Maximum Recommended Wall Cutout Dimensions



Contacting CyberData

Corporate Headquarters	Sales: (831) 373-2601 ext. 334 Support: 831-373-2601 ext. 333 Web: http://www.cyberdata.net/support/contactsupportvoip.html RMA Dept: (831) 373-2601 ext. 136 Email: RMA@CyberData.net RMA Status: http://www.cyberdata.net/support/rmestatus.html
Phone: 831-373-2601 Fax: 831-373-4193 www.CyberData.net	Warranty information is available at: Web: http://www.cyberdata.net/support/warranty/index.html

CyberData
The IP Endpoint Company

Installation Quick Reference

VoIP Indoor Emergency Intercom

SiP Compliant

011035


The CyberData SIP-enabled VoIP Indoor Emergency Intercom is a two-way communications device that is used in an area where either an emergency panic button or two-way priority communications are required.



Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address ^a	10.10.10.10
Web Access Username	admin
Web Access Password	admin
Subnet Mask ^a	255.0.0.0
Default Gateway ^a	10.0.0.1

a. Default if there is not a DHCP server present.


Typical System Installation




Getting Started

- Download the *VoIP Emergency Intercom Operations Guide* PDF file from the VoIP Indoor Emergency Intercom product page, at: <http://www.cyberdata.net/products/voip/digitalanalog/intercomemergency/docs.html>
- Create a plan for the locations of your Intercoms.
- Prior to installation, consult local building and electrical code requirements.
- WARNING: This enclosure is not rated for any AC voltages!**


Intercom Parts




Dimensions



Terminal Block Connections



Cable Connections



Gang Box Mounting Options

